

The PELSUE "D" STYLE GROUND TENT

Model 6510D

Size base 3m x 3m (erected) and 0.2m x 2m (folded) Weight 16.3Kgs (36lbs)
Door opening height 2m and max internal height to middle point 2.4m

To Erect:

The ***tent is stored inside-out***. The round rubber discs are in the middle of the sides and top when erected and the white poles are also on the inside of the tent. Unfold the tent carefully so that the ALL WHITE roof can be sprung out from the inside. Then working again from the inside push out the THREE sides. Use the guy ropes attached to the middle of the sides to stop the tent moving, due to wind etc.

Note: The tent is more stable if the wind is not blowing into the door opening.

To Collapse:

Working from the inside pull one side in at a time and lastly pull in the roof. From the outside carefully bring together all the poles and wrap the tent material around the poles, then place in the tent bag with the peg bag.



This is an example of TWO tents joined together

